


Article number: 00 500 00 99

SWS Server

Central computer unit for setting up a water management system and control for water-saving drinking water hygiene. Access via PC, mobile device via web app or building management system.



- Networking of up to 64 participants (e.g. fittings) via cable or radio (meshwork).
 - Participants can be individually parameterised centrally.
 - Centrally controlled stagnation flush (simultaneous).
- At fixed intervals and on fixed dates.



- When a temperature is exceeded/fallen below. - Triggered by an external signal (BMS, switch, etc.).

Scope of delivery

- SWS server
 - Integrated micro SD card

Technical data

- Programmable parameters (SWS server)
 - User rights management
 - Duration of flow
 - Energy saving mode
 - Trap flushing
 - Max. flow time
 - Post Runtime
 - Cleaning stop
 - Sensor range
 - Flush time
 - Stadium program
 - Stagnation flush
 - Thermal disinfection
 - Pre-flush
- Approved according to: DIN EN 61000-6-2:2005, DIN EN 61000-6-3:2006 + A1:2010, DIN EN 61000-6-3:2007 + A1:2011, DIN EN 61000-4-2:2009, EN 300328, EN 301 489-1, EN 301 489-17, DIN EN 60950-1:2006 / A12:2011

Delivery data

- Weight: 1,26 kg/Piece
- Packing unit: 1

Necessary associated articles

SWS Bus mains adapter Article no: 00 505 00 99
 SWS Bus extender cable BE-K Article no: 00 501 00 99 and/or

SWS Bus extender wireless BE-F

Article no: 00 502 00 99

and/or

Recommended associated articles

SWS Electrical distribution box

Article no: 00 506 00 99

Recommendation:**SMART.SWS**

SWS can be extended with SMART.SWS with little effort and thus offers greater clarity, effectiveness and economy of your SWS installation.

SMART.SWS offers the following advantages:

Graphical evaluation of the following data and thus clearer SWS operation

- The right view for everyone:
 - Property
 - Building
 - Water management system
- Stagnation flushes
- Thermal disinfections
- System messages
- Temperature curves
- Display of frequently and rarely used fittings
- Water quantities (calculated)
- Battery charge levels
- Remote access to the SWS server (separate password)

For organisational reasons, SMART.SWS can only be obtained from SCHELL.

SCHELL will be happy to advise you.

Mounting instructions

- Terminal strip and top-hat rail on site.
- For mounting on onsite 35 mm top-hat rail (according to EN 60715).